

Relay Socket



| Relay Socket | | | | |
|--------------|------------|-------------|------------|------------|
| 10FF-2Z-C1 | 10FF-2Z-C2 | 10FF-2Z-C3 | 10FF-2Z-C4 | 10FF-3Z-C1 |
| 10FF-3Z-C2 | 10FF-3Z-C3 | 10FF-3Z-C4 | 13F-2Z-A1 | 13F-2Z-A2 |
| 13F-2Z-A | 13F-2Z-B | 13F-2Z-C1 | 13F-2Z-C2 | 14FF-1Z-A1 |
| 14FF-1Z-C2 | 14FF-1Z-C3 | 14FF-1Z-C4 | 14FF-2Z-A1 | 14FF-2Z-C2 |
| 14FF-2Z-C3 | 14FF-2Z-C4 | 18FF-2Z-A1 | 18FF-2Z-A2 | 18FF-2Z-C1 |
| 18FF-2Z-C2 | 18FF-2Z-C3 | 18FF-2Z-C4 | 18FF-2Z-C5 | 18FF-2Z-C6 |
| 18FF-2Z-C7 | 18FF-2Z-C8 | 18FF-2Z-C9 | 18FF-3Z-A1 | 18FF-3Z-A2 |
| 18FF-3Z-C1 | 18FF-3Z-C4 | 18FF-3Z-C5 | 18FF-4Z-A1 | 18FF-4Z-A2 |
| 18FF-4Z-C1 | 18FF-4Z-C2 | 18FF-4Z-C3 | 18FF-4Z-C4 | 18FF-4Z-C5 |
| 18FF-4Z-C6 | 18FF-4Z-C7 | 18FF-4Z-C8 | 18FF-4Z-C9 | 41F-1Z-C2 |
| 118F-1Z-A1 | 118F-2Z-A1 | 140FF-2Z-C3 | HFAA | HFAB |
| HFBC | HFBD | HFBE | HFCF | HFCG |
| HFCH | HFDI | HFDJ | HFDK | HFEL |
| HFEM | HFEN | HFFO | HFFP | HFFQ |
| HFGR | HFGS | HFGT | HFHU | HFFAA |
| HFFAB | HFFBC | HFFBD | HFFBE | HFFCF |
| HFFCG | HFFCH | HFFDI | HFFDJ | HFFDK |
| HFFEL | HFFEM | HFFEN | HFFFO | HFFFP |
| HFFFQ | HFFGR | HFFGS | HFFGT | HFFHU |
| HFHAA | HFHAB | HFHBC | HFHBD | HFHBE |
| HFHCF | HFHCG | HFHCH | HFHDI | HFHDJ |
| HFHDK | HFHEL | HFHEM | HFHEN | HFHFO |
| HFHFP | HFHFQ | HFHGR | HFHGS | HFHGT |
| HFHHU | | | | |

REHAG ELEKTRONIK – Bereich Industrieelektronik

Tel. 04261 / 9388-0 FAX. 04261 / 9388-999

info@rehag.de – www.rehag.de